

L'ÉCLAT DE CARAFE

MEASUREMENTS

22cm diameter / 30cm height

MATERIALS

Iron, Glass

CORD

200 cm (adjustable)

POWER USAGELED LIFESPANDIMMABLE≤36V50.000+ hoursNot dimmable

LIGHT SOURCEWEIGHTLIGHT COLOR TEMPERATUREE27, Included (replacable)2.58KG3000K

IMPORTANT SAFETY INFORMATION:

- 1. Turn off the power at the circuit breaker or fuse box before installation.
- 2. For safety and to ensure compliance with local electrical codes, it is recommended that installation be carried out by a qualified electrician or experienced installer.
- 3. Handle with care. The lamp is reasonably scratch-resistant, but it still requires careful handling.

INSTALLATION

- Turn Off Power: Ensure the power is turned off at the main circuit breaker before proceeding.
- Secure the Ceiling Plate: Attach the ceiling plate using the provided screws. Ensure it is level and firmly secured to support the weight (2.58 kg).
- Connect Fixture Wires: Connect the fixture wires to the ceiling wires: Black (live) to black, White (neutral) to white, Green/Yellow (ground) to the ground wire, Use wire connectors to secure the connections.
- Attach the Fixture: Mount the lamp to the secured ceiling plate.
- Adjust the Cord: Adjust the cord to your desired length (up to 200 cm) before tightening everything securely.
- Light Source: The LED light source (E27) is included and replaceable, so no additional installation is needed.
- Restore Power: Turn the power back on and test the lamp.

ADDITIONAL TIPS

• Maintenance: Clean the lamp regularly with a soft, dry cloth to remove dust. Avoid using harsh cleaning agents to protect the delicate materials.

NOTE

If you have any additional questions or requests, feel free to contact us via our contact page. You can easily place orders for our items via our website.