

LA TRUFFLE ENCHANTÉE MINI

MEASUREMENTS

16*28cm

MATERIALS

Metal

CORD

Wireless (USB-C included)

POWER USAGE CHARGED CAPACITY DIMMABLE

<36V Up to 20 hours Three-Color Adjustable (Touch)

LIGHT SOURCE WEIGHT LIGHT COLOR TEMPERATURE
Included LED lights 800GR 3000-6000K

EXTRA INFORMATION

- Easy to install
- Not intended for outdoor use. Keep out of the sun at all times.
- Please wipe the lamp with soft and dry cloth. Do not wipe with wet towel.
- Do not keep the product within reach of infants and young children.
- Do not expose the product to high temperatures or direct sunlight for a long time.
- Do not look directly in the light source when lighting
- Never open, disassemble or modify the product.
- Please disconnect the product immediately if you feel smoke or something burning.
- Do not place the product on unstable or inclined surfaces.
- Use and store products between 0°C and 40°C.
- Please use the lamp strictly according to the above requirements.

HOW TO USE

- Charge the Lamp: Connect the charging cable to the lamp and a power source. Let it fully charge before using. An indicator light will signal when it's ready.
- Turn On the Lamp: Press the power button on the base or side to turn it on. Hold the button for 2-3 seconds if necessary.
- Adjust & Enjoy: Use the button to change brightness levels or modes. Once charged, place the lamp anywhere and enjoy wireless lighting!

NOTE

If you have any additional questions or requests, feel free to contact us via our contact page. You can easily place orders for our items via our website.