



LE SAVOY

MEASUREMENTS

13cm diameter / 28.5cm height

MATERIALS

Aluminium, Acrylic sheet

CORD

Wireless, USB-C Charging

CHARGING TIME

3-5 hours

BATTERY CAPACITY

2200mAh

DIMMABLE

Three-Color Adjustable (Touch)

LIGHT SOURCE

Included

WEIGHT

480GR

LIGHT COLOR TEMPERATURE

3000-4000-6000K

EXTRA INFORMATION

- To ensure longevity, avoid leaving the product outdoors for extended periods to prevent damage from harsh weather and direct sunlight.
- Clean the lamp with a soft, dry cloth only. Do not use a wet towel.
- Keep out of reach of infants and young children.
- Avoid exposing the product to high temperatures or direct sunlight for prolonged periods.
- Do not look directly into the light source when illuminated.
- Never open, disassemble, or modify the product.
- If you detect smoke or burning smells, disconnect the product immediately.
- Avoid placing the lamp on unstable or inclined surfaces.
- Use and store the product in environments with temperatures between 0°C and 40°C.
- Adhere strictly to the above usage instructions.

HOW TO USE

- Charge the Lamp: Connect the USB-C charging cable to the lamp and a power source. Allow it to fully charge for 3 hours. An indicator light will signal when charging is complete.
- Turn On the Lamp: Press the power button located on the base or side of the lamp to turn it on. Hold the button for 2-3 seconds if necessary.
- Adjust & Enjoy: Use the touch button to change brightness levels or color modes (3000K, 4000K, 6000K). Once charged, place the lamp anywhere and enjoy wireless lighting!

NOTE

If you have any additional questions or requests, feel free to contact us via our contact page. You can easily place orders for our items via our website.